




Issue C



Item	Part No.	Description	Item	Part No.	Description
1	008/DB136	Cook Plate Seal	40	008/FFM091	Door Catch Roller
2	008/DB005	Fire Door Seal	41	008/DB071	Door Insulation
3*	008/FW29	Door Seal Adhesive	42	004/DB070	Door Back
4	008/DB072	Oven Door Seal	43	008/DB073	Thermometer Gasket
5	008/DB137	Access Door Seal	44	008/DB074	Bimetal Thermometer
6	006/DB018	Glass	45#	003/DB004A	Access Door Assembly
7	008/DB003	Glass Seal	46	008/DB110	Gasket
8	004/KV23	Glass Retainer	47	010/DB020	Air Control Mounting Box
9	011/DB031	Throat Plate	48	008/DB109	Air Control Gasket
10	004/XV30	Brick Bracket	49	008/DB108	Air Control Cover Gasket
11	011/DB029S	Brick Set	50	010/DB130	Air Control Plate
12	011/DB034	Left Side Top Brick	51	004/DB115	Air Control Slider
13	010/DB015R	Right Side Fireplate	52	004/BR015	Clicker Retainer
14	010/DB015L	Left Side Fireplate	53	008/ES36/01	Brass Ball Catch
15	010/DB016	Back Fire Plate	54	004/DB081	Air Control Heat Shield
16	002/DB008	Deepening Bar	55	004/DB040	Air Control Cover
17	002/DB007	Front Fence	56	008/CR048	Spigot
18	002/SY30	Carrier Bar	57	008/CR063	Duct Gasket
19	012/DB077	Idler Rod	58	004/CR064	Blanking Plate
20	012/DB078	Riddler Rod	59	008/BR052	Felt Washer
21	012/SY33	Mover Bar	60	004/EZ016	Air Control Rod
22	002/CG015S	Fire Bar (Set of 5)	61	008/AY37	Air Control Knob
23	004/DB017	Ashpan	62	001/DB010	Firebox
24	002/DB098	Riddling Boss	63	012/DB011	Serial Label
25	012/EZ095	Riddler Handle	64	010/DB009	Cook Plate
26	008/ST073/4	Hinge Pin (Set of 4)	65#	010/CY65S	Legs Set
27	004/AP025	Spacer	66#	010/DB087	Store Stand
28#	002/AP024	Hinge	67	010/BU034	Vertical Rear Flue Adaptor
29#	003/DB001A	Fire Door Assembly	68#	002/PV12B	Flue Collar
30	008/KV13	Left Hand Door Knob	69	008/KS134	Sealing Gasket (Flue)
31	008/KV16	Door Handle	70	004/DB090	Oven Assembly
32	002/AY14	Door Catch	71	008/DB092	Oven Shelf
33	008/FFW008	M12.5 Washer	72	010/DB013	Damper Assembly
34	008/FFW005	M8 Washer	73	008/FFP017	Main Oven Striker Pin
35	008/FFN001	M12 Half Nut	74	010/DB082	Lower Heat Shield Assembly
36	004/ST008	Tabbed Locking Washer	75#	010/DB080	Heat Shield
37	008/FFW015	Thackery Washer	76#	010/DB051S	Rear Shelf Kit (Optional Extra)
38#	003/DB002A	Oven Door Assembly	77#	010/DB056	Flame Guard (Optional Extra)
39	008/DB047	Oven Door Handle	78	004/DB094	Baking Tray (Optional Extra)

*These items are not shown on the drawing.

Please specify colour when ordering. Prices are shown in pounds sterling with vat at 20% They are correct at the date shown but may be subject to change without notice. E. & O.E These prices are subject to a carriage charge.

To obtain spare parts please contact your local stockist giving Model, Part No. and Description. In case of difficulty contact the manufacturer at the address shown. This drawing is for identification purposes only.

