

OPERATING AND INSTALLATION INSTRUCTIONS

KUBE 10 STOVE

is exempt for use in smoke control areas when burning dry wood.



www.hetaheating.com

ECODESIGN




EN

DANISH DESIGN . DANISH QUALITY . DANISH PRODUCTION


www.pieces-de-poele.com

1.21 Parts Door



Pos. no.	Name	Qty	L = 0.334	Pos. no.	Name	Qty
1 0008-1036	M4x6 Hexagon socket cap screw	9		8 1013-0432	Glass clips, small	4
2 0008-2055	M5x16 Hexagon socket button head	2		9 6000-030745	Shutter roller	1
3 0008-030946	Bush	4		10 6000-031743	Door, complete	1
4 0008-3503	M6/12x1,6 Washer BN 560 Brass	1		11 0008-0212	M6x10 Hexagon locking screw	2
5 0021-030746	Glass	1		12 0030-030958	Air control handle	1
6 0023-3008	Glass gasket L=1,54 m ø12	1		13 6000-031892	Handle	1
7 0023-3010	Textile glass 6 mm with adhesive black	4				

Inside fire chamber



Pos. no.	Name	Qty
1 0023-030997	Bottom stone, left	1
2 0023-030998	Side stone, right	1
3 0023-030999	Back stone, bottom	1
4 0023-031000	Front stone	1
5 0023-031001	Back stone, top	1
6 0023-031002	Baffle	1
7 0023-031285	Side stone, left	1
8 0023-031467	Bottom stone, right	1
9 1011-0137	Tertiary nozzle	1
10 0023-3008	Glass cord ø12 mm L = 0.25 m	1