

Itaca 80 calefactora R12, Itaca 80 calefactora R18

Manual de instruções





6. CORTES BÁSICOS

Nº	Código	Denominación	Cant.	CODIGO
1	IC-634	Marco exterior Itaca 80	1	504120000033
2	IC-618	Cristal puerta 702x482Itaca 80	1	504120000034
3		Cordón cerámico 15x10mm puerta Itaca 80	1	504000000068
4	IC-089	Parrilla base hogar Itaca 80-100-120	1	504000000058
5	IC-433	Cjto. sist. cierre puerta DCHA Itaca 80-100-120	1	504000000057
6	IC-577	Cjto. sist. cierre puerta IZQDA Itaca 80-100-120	1	504000000058
7	IC-964	Deflector medio Itaca 80 R12 calefactora	1	504320000000
	IC-890	Deflector medio Itaca 80 R18 calefactora	1	504330000000
	IC-965	Deflector superior Itaca 80 R12 calefactora	1	504320000001
8	IC-909	Deflector superior Itaca 80 R18 calefactora	1	504330000001
	IC-970	Amarre SUP- IZQ refractarios ITACA 80 calefactora R12	1	504320000002
9	IC-901	Amarre SUP- IZQ refractarios ITACA 80 calefactora R18	1	504330000002
	IC-971	Amarre SUP-DCHO refractarios ITACA 80 Calefactora R12	1	504320000003
10	IC-905	Amarre SUP-DCHO refractarios ITACA 80 Calefactora R18	1	504330000003
	IC-968	Cjto. base hogar ITACA 80 Calefactora R12	1	504320000004
11	IC-914	Cjto. base hogar ITACA 80 Calefactora R18	1	504330000004
	IC-563	Subens. cenicero ITACA-INCA	1	504000000065
13	REF-016	Refractario 420x154x30 Hogar Chimeneas calefactoras		500000000836
14	REF-015	Refractario 420x234x30 Hogar Chimeneas calefactoras		500000000837

